

# DMX CHARTS

Channel	8 Ch	10 Ch	14 Ch	20 Ch	34 Ch	44 Ch
1	1Cell Red	1Cell Red	1Cell Dimmer	1Cell Dimmer	1Cell Red 1	1Cell Dimmer
2	1Cell Green	1Cell Green	1Cell Red	1Cell Red	1Cell Green 1	1Cell Strobe 1
3	1Cell Blue	1Cell Blue	1Cell Green	1Cell Green	1Cell Blue 1	1Cell Strobe 2
4	1Cell White	1Cell White	1Cell Blue	1Cell Blue	1Cell White 1	1Cell Strobe 3
5	2Cell Red	1Cell Dimmer Speed Mode	1Cell White	1Cell White	1Cell Red 2	1Cell Strobe 4
6	2Cell Green	2Cell Red	1Cell Strobe	1Cell Strobe	1Cell Green 2	1Cell Red 1
7	2Cell Blue	2Cell Green	1Cell Dimmer Speed Mode	1Cell Color Macro	1Cell Blue 2	1Cell Green 1
8	2Cell White	2Cell Blue	2Cell Dimmer	1Cell Effects	1Cell White 2	1Cell Blue 1
9		2Cell White	2Cell Red	1Cell Effects speed	1Cell Red 3	1Cell White 1
10		2Cell Dimmer Speed Mode	2Cell Green	1Cell Dimmer Speed Mode	1Cell Green 3	1Cell Red 2
11			2Cell Blue	2Cell Dimmer	1Cell Blue 3	1Cell Green 2
12			2Cell White	2Cell Red	1Cell White 3	1Cell Blue 2
13			2Cell Strobe	2Cell Green	1Cell Red 4	1Cell White 2
14			2Cell Dimmer Speed Mode	2Cell Blue	1Cell Green 4	1Cell Red 3
15				2Cell White	1Cell Blue 4	1Cell Green 3
16				2Cell Strobe	1Cell White 4	1Cell Blue 3
17				2Cell Color Macro	1Cell Dimmer Speed Mode	1Cell White 3
18				2Cell Effects	2Cell Red 1	1Cell Red 4
19				2Cell Effects speed	2Cell Green 1	1Cell Green 4
20				2Cell Dimmer Speed Mode	2Cell Blue 1	1Cell Blue 4
21					2Cell White 1	1Cell White 4
22					2Cell Red 2	1Cell Dimmer Speed Mode
23					2Cell Green 2	2Cell Dimmer

					2Cell Blue 2	2Cell Strobe 1
					2Cell White 2	2Cell Strobe 2
					2Cell Red 3	2Cell Strobe 3
					2Cell Green 3	2Cell Strobe 4
					2Cell Blue 3	2Cell Red 1
					2Cell White 3	2Cell Green 1
					2Cell Red 4	2Cell Blue 1
					2Cell Green 4	2Cell White 1
					2Cell Blue 4	2Cell Red 2
					2Cell White 4	2Cell Green 2
					2Cell Dimmer Speed Mode	2Cell Blue 2
						2Cell White 2
						2Cell Red 3
						2Cell Green 3
						2Cell Blue 3
						2Cell White 3
						2Cell Red 4
						2Cell Green 4
						2Cell Blue 4
						2Cell White 4
						2Cell Dimmer Speed Mode

8 Ch	10 Ch	14 Ch	20 Ch	34 Ch	44 Ch	FUNCTION	DMX Value	Default
		1	1		1	<b>1Cell Dimmer</b> 0~100%	000 - 255	
1	1	2	2			<b>1Cell Red</b> 0~100%	000 - 255	
2	2	3	3			<b>1Cell Green</b> 0~100%	000 - 255	
3	3	4	4			<b>1Cell Blue</b> 0~100%	000 - 255	
4	4	5	5			<b>1Cell White</b> 0~100%	000 - 255	
		6	6			<b>1Cell Strobe</b> No Function Strobe Slow to Fast	000-010 011-255	
					2	<b>1Cell Strobe1</b> No Function Strobe Slow to Fast	000-010 011-255	
					3	<b>1Cell Strobe2</b> No Function Strobe Slow to Fast	000-010 011-255	
					4	<b>1Cell Strobe3</b> No Function Strobe Slow to Fast	000-010 011-255	
					5	<b>1Cell Strobe4</b> No Function Strobe Slow to Fast	000-010 011-255	
				1	6	<b>1Cell Red1</b> 0~100%		
				2	7	<b>1Cell Green1</b> 0~100%		
				3	8	<b>1Cell Blue1</b> 0~100%		
				4	9	<b>1Cell White1</b> 0~100%		
				5	10	<b>1Cell Red2</b> 0~100%		
				6	11	<b>1Cell Green2</b> 0~100%		
				7	12	<b>1Cell Blue2</b> 0~100%		
				8	13	<b>1Cell White2</b> 0~100%		
				9	14	<b>1Cell Red3</b> 0~100%		
				10	15	<b>1Cell Green3</b> 0~100%		
				11	16	<b>1Cell Blue3</b> 0~100%		
				12	17	<b>1Cell White3</b> 0~100%		

				13	18	<b>1Cell Red4</b> 0~100%		
				14	19	<b>1Cell Green4</b> 0~100%		
				15	20	<b>1Cell Blue4</b> 0~100%		
				16	21	<b>1Cell White4</b> 0~100%		
			7			<b>1Cell Color Macro</b> No Function R 100%, G 0~100%, B 0% R 100%~0%, G 100%, B 0% R 0%, G 100%, B 0~100% R 0% G 100%~0% B 100% R 0%~100% G 0% B 100% R 100% G 0% B 100%~0% R 100% G 0%~100% B 0%~100% R 100%~0% G 100%~0% B 100% R 100% G 100% B 100% W100% Color1(2800K) Color2(3000K) Color3(3200K) Color4(4000K) Color5(5600K) Color6(6000K) Color7(6500K) Color8(7000K) Color9(8000K) Color10(9000K) Color11(10000K)	000~010 011~030 031~050 051~070 071~090 091~110 111~130 131~150 151~170 171~200 201~205 206~210 211-215 216-220 221-225 226-230 231-235 236-240 241-245 246-250 251-255	
			8			<b>1Cell Effects</b> No Function Effect 1 Effect 2 Effect 3 Effect4 Effect5 (Effects1- 4) Effect 6 Effect 7 Effect 8 Effect 9 (Effects6- 8)	000-010 011-037 038-064 065-091 092-118 119-145 146-172 173-199 200-226 227-255	
			9			<b>1Cell Effects speed</b> Effects speed slow to fast	000 - 255	
	5	7	10	17	22	<b>1Cell Dimmer Speed Mode</b> Preset dimmer speed from display menu Dimmer speed mode off Dimmer speed mode1 (fast speed) Dimmer speed mode2 (middle speed) Dimmer speed mode3 (slow speed)	000-051 052-101 102-152 153-203 204-255	
		8	11			<b>2Cell Dimmer</b> 0~100%	000 - 255	
5	6	9	12			<b>2Cell Red</b> 0~100%	000 - 255	
6	7	10	13			<b>2Cell Green</b> 0~100%	000 - 255	
7	8	11	14			<b>2Cell Blue</b> 0~100%	000 - 255	

8	9	12	15			<b>2Cell White</b> 0~100%	000 - 255
					23	<b>1Cell Dimmer</b>	000 - 255
		13	16			<b>2Cell Strobe</b> No Function Strobe Slow to Fast	000-010 011-255
					24	<b>2Cell Strobe1</b> No Function Strobe Slow to Fast	000-010 011-255
					25	<b>2Cell Strobe2</b> No Function Strobe Slow to Fast	000-010 011-255
					26	<b>2Cell Strobe3</b> No Function Strobe Slow to Fast	000-010 011-255
					27	<b>2Cell Strobe4</b> No Function Strobe Slow to Fast	000-010 011-255
				18	28	<b>2Cell Red1</b> 0~100%	000 - 255
				19	29	<b>2Cell Green1</b> 0~100%	000 - 255
				20	30	<b>2Cell Blue1</b> 0~100%	000 - 255
				21	31	<b>2Cell White1</b> 0~100%	000 - 255
				22	32	<b>2Cell Red2</b> 0~100%	000 - 255
				23	33	<b>2Cell Green2</b> 0~100%	000 - 255
				24	34	<b>2Cell Blue2</b> 0~100%	000 - 255
				5	35	<b>2Cell White2</b> 0~100%	000 - 255
				26	36	<b>2Cell Red3</b> 0~100%	000 - 255
				27	37	<b>2Cell Green3</b> 0~100%	000 - 255
				28	38	<b>2Cell Blue3</b> 0~100%	000 - 255
				29	39	<b>2Cell White3</b> 0~100%	000 - 255
				30	40	<b>2Cell Red4</b> 0~100%	000 - 255
				31	41	<b>2Cell Green4</b> 0~100%	000 - 255
				32	42	<b>2Cell Blue4</b> 0~100%	000 - 255
				33	43	<b>2Cell White4</b> 0~100%	000 - 255

	10	14		34	44	<b>2Cell Dimmer Speed Mode</b> Preset dimmer speed from display menu Dimmer speed mode off Dimmer speed mode1 (fast speed) Dimmer speed mode2 (middle speed) Dimmer speed mode3 (slow speed)	000-051 052-101 102-152 153-203 204-255	
					17	<b>2Cell Color Macro</b> No Function R 100%, G 0~100%, B 0% R 100%~0%, G 100%, B 0% R 0%, G 100%, B 0~100% R 0% G 100%~0% B 100% R 0%~100% G 0% B 100% R 100% G 0% B 100%~0% R 100% G 0%~100% B 0%~100% R 100%~0% G 100%~0% B 100% R 100% G 100% B 100% W100% Color1(2800K) Color2(3000K) Color3(3200K) Color4(4000K) Color5(5600K) Color6(6000K) Color7(6500K) Color8(7000K) Color9(8000K) Color10(9000K) Color11(10000K)	000~010 011~030 031~050 051~070 071~090 091~110 111~130 131~150 151~170 171~200 201~205 206~210 211-215 216-220 221-225 226-230 231-235 236-240 241-245 246-250 251-255	
					18	<b>2Cell Effects</b> No Function Effect 1 Effect 2 Effect 3 Effect4 Effect5 (Effects1- 4) Effect 6 Effect 7 Effect 8 Effect 9 (Effects6- 8)	000-010 011-037 038-064 065-091 092-118 119-145 146-172 173-199 200-226 227-255	
					19	<b>2Cell Effects speed</b> Effects speed slow to fast	000-255	
	10	14	20			<b>2Cell Dimmer Speed Mode</b> Preset dimmer speed from display menu Dimmer speed mode off Dimmer speed mode1 (fast speed) Dimmer speed mode2 (middle speed) Dimmer speed mode3 (slow speed)	000-051 052-101 102-152 153-203 204-255	